



ALPINE (3 Head) MAGICAL POND FOGGER W/ LED LIGHTS INSTALLATION AND INSTRUCTIONS.

The Alpine Magical Pond Fogger with LED Lights will enhance the beauty and atmosphere of any small pond or large water feature. The Magical Pond Fogger is Fish Safe, and will create a mystical pond fog within seconds. Simply place the Alpine Magical Pond Fogger into the floating ring and watch it marvel! Try using it in a Halloween decoration. Children will marvel at its mystical effect.

This Alpine Magical Pond Fogger has been specifically manufactured to our specifications to produce the optimal amount of Super Fog with the finest quality of products. The parts and materials used for this unit are all superior parts to allow optimal operating performance and longevity of your Super Power Pond Fogger. If it doesn't say Alpine, it's not an Alpine Fogger.

This package includes:

1. 3 Head Magical Pond Fogger Unit with NEW LED Lights
2. Floating Ring
3. Outdoor Transformer

CAUTION! Before Assembly or Operating Please Read.

1. Use the specified transformer supplied.
2. Do not put your hand above the fogger while it is operating. The high vibration could cause injury.
3. Disconnect power supply before removing fogger or during maintenance.

Assembly and Operating Instructions

1. Place the Magical Pond Fogger into the floating ring (included).
2. Place the unit (including the floating ring) into the pond or large water feature.

3. Plug the Magical Pond Fogger into the output socket of the transformer.
4. Plug transformer into AC power socket, indicators of Super Power Pond Fogger unit will light up, which means the unit is now running.

General Instructions for Optimal Usage

1. Suggested usage of the Magical Pond Fogger is no more than 8 hours per day. Connecting a timer to your transformer will insure your pond fogger to be used only when needed. Clean water is recommended.
2. Clean the Magical Pond Fogger with a soft cloth approximately twice per month.
3. When cleaning the Magical Pond Fogger do not use chemical cleaners.
4. Take care of the water level sensor switch, do not hold it to move the unit around, scratch it, or bump it with anything hard. It will damage the sensor level switch if it is not properly maintained.

Maintenance and Service

(Ceramic Disk Replacement Tool Kit Sold Separately)

1. Ceramic Disks must be cleaned at least one time per month (twice recommended). Use of a cotton swab to clean the dirt on the surface is recommended.
2. Take special care not to scratch the ceramic disc or water switch of the Super Power Pond Fogger.
3. After using the Pond Fogger for about 3000 hours, the quantity of the fog will start to decline or the unit may even stop working. Replacing the ceramic disc (sold separately) will insure continued operation. Please refer to replacing the disk on the drawing.
4. Replacement discs, and tools are available from your local dealer. Refer to drawing number 1 for replacing disks instructions.
 - a. Unplug the unit and remove from water container.
 - b. Using the Alpine tool kit, insert the key into the winding ring and turn counter clockwise.

- c. Remove the filler piece (washer) and ceramic. **IMPORTANT**, note that there is a front and back of the ceramic disk. Be sure to reinstall the correct side facing up. (The washer should not be faced up)
- d. Clean chemical deposits on the ceramic with a soft cloth and reinstall or proceed to install a new ceramic disk in the reverse order above. Refer to illustrated instructions below. (Drawing No. 1)
- e. The inside of the unit cavity must be completely dry before the parts are installed.
- f. Using new ceramic disks is needed if they cannot produce fog normally after cleaning.

repaired or replaced at Alpine's option – free of charge (less shipping charges). Unless in the dealers or Alpine's opinion it has been damaged or misused the guarantee will be void. To obtain the benefits of this guarantee send the Magical Pond Fogger with LED Lights back along with proof of purchase direct to Alpine.

Note: This guarantee does not include the replacements of the tool kits. Be sure to pour clean water and replace water in the glass bowl timely.

Parameters of The Super Pond Fogger Unit:


TECHNICAL DATA

Working Voltage (VAC)	Working Electric Current (A)	Ultrasonic Frequency(KHz)	Ceramic disc spec. (mm)
36	2.6 ~ 2.9	1700±40	Φ20


Generate mist (ml/h)	Water temp. Range (°C)	Ceramic disc plated material	Lifespan of Ceramic Disc (hour)
≥900	0 ~ 50	Nickel or Titanium	>3000

Alpine 1-Year Guarantee

If this product becomes unserviceable or defective within one year of the date of purchase from your dealer, after your dealer has been contacted, it will be



Drawing No. 1



Drawing No. 2